



USER MANUAL

**To ensure safety while driving
and to comply with laws,
drivers should not watch video or
operate the video device while driving.**

PRECAUTION

Class 1 laser product

This car multi-media player is a class 1 laser product. However This car multi-media player uses a visible/invisible laser beam which could cause . Hazardous radiation exposure if directed.

Be sure to operate the car multi-media player correctly as instructed. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. Do not open covers and do not repair yourself. Refer servicing to qualified personnel.


Content

Precaution.....	1
Content.....	2
Installation steps.....	3
General knowledge about remote control.....	7
Locations and Names of controls on main unit.....	8
Locations and Names of controls on remote control.....	9
Same functions in any work source mode.....	10
Radio operation.....	17
BT Operation.....	20
Disc/USB/card operation.....	23
1. Loading or unloading a disc, USB or card.....	23
1.1 Loading a disc, USB or card.....	23
1.2 Unloading a disc, USB or card.....	24
2. Popping up Function Icons-board.....	24
2.1 Function Icons-board of Digital Video/VCD/MPEG4/Image /MP3/WMA.....	24
2.2 CD interface.....	25
3. Function of controls on the touch screen/main unit/remote control.....	26
* Region Code.....	35
* Parental Control.....	36
AUX IN operation.....	37
External iPod operation.....	38
Rear View Camera.....	39
Operation of GPS module.....	40
1. GPS Navigation.....	40
2. MEDIA/PHOTO/VIEWER.....	41
Media operation.....	41
Photo operation.....	42
Reader operation.....	42
Calculator and Calendar.....	44
1. Calculator.....	44
2. Calendar.....	44
GAME.....	45
Troubleshooting.....	46
Specification.....	47


INSTALLATION STEPS

1. Remove the chassis from Slide Bracket Housing ;

1) Press the REL button to release the control panel ;



2) Hold the right side of the control panel to pull it upwards a little and then to you for removing it ;



3) Remove the PLASTIC FRAME from the chassis (see the Installation diagram);


4) Insert the 2 KEY PLATES into the grooves at the both sides of the chassis till they click(see the Installation diagram);

5) Pulling the two KEY PLATES to remove the chassis from the Slide Bracket Housing ;

2. Mount the Sliding Bracket Housing in the position of car multi-media system and bend some tabs of Sliding Bracket Housing to fix it.

3. Connecting all wires:

1) Connecting all wires according to the wiring diagram on next page;



WIRING DIAGRAM


NOTE:

1. Must use 4 ohms impedance of speakers.
2. After connecting parking Line, video on screen of control panel will be displayed only after applying parking brake.
3. Before finishing wiring, do not attach control panel onto chassis.

2) Attaching the control panel onto the chassis;

(1) Insert the left side of the control panel into the hollow of the chassis .
(NOTE : the “bulge” point on the control panel must be attached into the hollow of the chassis .)

(2) Gently push the right side of the control panel till you feel a “ Click” .



3) Testing it for making sure that it can work properly .

4. Installing chassis according to the installation diagram on next page:

1) Insert the chassis of the car multi-media system into the Sliding Bracket Housing.

2) Use the metal strap to fix the rear part of chassis.

* Uninstalling the chassis:



1) Remove the metal strap from the chassis ;

2) Remove the control panel from the chassis;

3) Remove the plastic frame from the chassis;

4) Insert 2 key plates into the left and right sides of the chassis and draw the chassis out of the sliding bracket housing.

Installation Diagram




If you want to take CHASSIS out of the SLIDE BRACKET HOUSING, first remove the PLASTIC TRIM OUT of the both sides away, then insert the two KEY PLATE into left and right side of chassis as above illustration.

GENERAL KNOWLEDGE ABOUT REMOTE CONTROL

1. Removing insulating sheet

If using remote control for the first time, you can see an insulating sheet at the bottom side of remote control as right.


you must remove the insulating sheet as right. Otherwise, the remote control is disabled.



2. Replace lithium cell


If the electric energy of lithium cell is weak, replace it.

- 1) Press and hold the movable block as direction indicated by arrow 1 as right, at one time pull cell holder out of remote control as direction indicated by arrow 2 as right.



- 2) Replace the old cell by a new one with (+) polarity side upward as right.

- 3) Insert the cell holder into remote control again as right.




3. Note about using remote control

- 1) You should face the emitting window of remote control towards the sensor window of the unit.
- 2) Operation angle for front panel: About 30 degree
- 3) The distance between the emitting window of remote control and the sensor window of the unit : < 5M .


4. Warning for lithium cells of remote control

- 1) Cell leakage may cause damage to remote control.
- 2) Do not throw cells into fire, it may cause explosion.
- 3) To avoid risk of accident, keep cells out of reach of children.

Locations and Names of Controls on Main Unit




Control Panel



Main Unit Face after removing Control Panel

- | | |
|----------------------------|-------------------------------|
| 1. AUX IN JACK (A/V) | 10. MUTE or PTY BUTTON |
| 2. USB PORT | 11. BAND or PAIR BUTTON |
| 3. SEL BUTTON and VOL KNOB | 12. > or CH1-6 BUTTON |
| 4. REL BUTTON | 13. >> or HANG UP BUTTON |
| 5. IR SENSOR WINDOW | 14. << or CALL BUTTON |
| 6. RESET BUTTON | 15. SD/MMC CARD SLOT |
| 7. EJECT BUTTON | 16. LCD SREEN |
| 8. POWER or MODE BUTTON | 17. OPEN/MONITOR-ANGLE BUTTON |
| 9. TA or AF BUTTON | 18. MICROPHONE |
| | 19. GPS CARD SLOT |

Locations and Names of Controls on Remote Control



- 16. VOL- BUTTON
- 17. SEL BUTTON
- 18. SETUP BUTTON
- 19. GOTO or * BUTTON
- 20. >|| BUTTON
- 21. STOP BUTTON
- 22. AUDIO or MO/ST BUTTON
- 23. ZOOM BUTTON
- 24. EQ or LOUD BUTTON
- 25. CLK BUTTON
- 26. ^ BUTTON

- 1. POWER/MODE BUTTON
- 2. MUTE BUTTON
- 3. HANG UP or REDIAL BUTTON
- 4. MONITOR-ANGLE BUTTON
- 5. CALL or PAIR BUTTON
- 6. MENU or SW BUTTON
- 7. >> BUTTON
- 8. SUBTITLE or LO/DX BUTTON
- 9. < BUTTON
- 10. BAND or OSD BUTTON
- 11. << BUTTON
- 12. A/PS or TITLE/PBC BUTTON
- 13. TOP BUTTON
- 14. VOL+ BUTTON
- 15. RDM BUTTON
- 27. >>| BUTTON
- 28. ENTER BUTTON
- 29. > BUTTON
- 30. V BUTTON
- 31. |<< BUTTON
- 32. INT BUTTON
- 33. NUMBER(0~9) BUTTON
- 34. +10 or # BUTTON
- 35. AF BUTTON
- 36. TA BUTTON
- 37. RPT BUTTON

Same functions in any work source mode

1. POWER button
In power off mode, pressing POWER button on remote control or pressing POWER button on control panel powers on main unit.

In power on mode, long pressing POWER button on control panel or on remote control powers off main unit.
2. VOL knob & VOL+/VOL- buttons
To adjust volume level, rotate VOL knob on control panel or press or hold VOL+ or VOL- button on remote control.
3. SEL button
To switch between TREBLE, BASS, BALANCE, FADER, COLOR, BRIGHT, CONTRAST, TINT and VOLUME, briefly and repeatedly press SEL button.

After switching on the desired mode above, rotate VOL knob or press VOL+/VOL- buttons to set it.

To switch between BT, REGION, PI, TA, AF, LOUD, SWF VOL, SWF FREQ, EQ, DX/LOCAL (in radio mode), STEREO/MONO (in radio mode), CLOCK FORMAT, CLOCK, BUZZER, FREQ AREA and LED COLOR, long press SEL button to switch on BT, then briefly and repeatedly press SEL button.

After switching on the desired mode above, rotate VOL knob or press VOL+/VOL- buttons to set it.
4. MUTE button
To switch MUTE mode on or off, press MUTE button on remote control or press MUTE button on control panel.
5. EQ button
To select a desired preset EQ mode from JAZZ, CLASSIC, POP, ROCK and USER, press EQ button on remote control continuously.
6. To switch LOUD mode
To switch LOUD mode between LOW, MIDDLE, HIGH and OFF, long press LOUD button.
7. SW button
To switch SWF FREQ between 80HZ, 120HZ and 160HZ, long press SW button on remote control.
8. CLK button
Press CLK button on remote control to display clock time .
9. OPEN or  and  buttons
To slide the monitor out and stand it up or into the monitor slot, press OPEN button on control panel or press  button on remote control;


To adjust the angle of the monitor, long press  button on remote control or on control panel .
10. MODE button and source menu
To switch work source between RADIO, DISC (after inserting a disc), USB (after inserting a USB storage), CARD (after inserting a card), AUX and BT MUSIC, press MODE button on remote control or press MODE button on control panel continuously.

During disc (non-CD)/USB/card playback, touch screen to pop up Function Icons-board and then touch the  icon in the Function Icons-board to enter the display status of the source menu before entering Disc/USB/Card mode (refer to Disc/USB/Card Operation) .

During AUX playback, touch screen to pop up AUX interface and then touch AUX icon to enter the display status of the source menu before entering AUX mode (refer to AUX operation).

In radio, BT music or CD mode, touch RADIO, BT or DISC icon to enter the display status of the source menu before entering radio, BT music or CD mode (refer to Radio Operation, BT Operation and Disc/USB/Card Operation).

The home page of the source menu displays as follows:




In the middle column, clock time displays in the top of it; the SN. And name of each page of the source menu display in the middle and bottom of it.

Touch any place on the screen and hold and then slide leftwards or rightwards to turn pages of the source menu. There are 4 pages in all as follows:

1) Home page




2) Tools page



3) Games page



4) Setup page



Touch one icon in the home page of the source menu to enter one work source of RADIO, DISC, USB, CARD, AUX, BT and others.

11.SYSTEM icon

In the setup page of the source menu, touch SYSTEM icon to display page1 of SETTINGS MENU as follows:



Page1 of SETTINGS MENU



Page2 of SETTINGS MENU

In the SETTINGS MENU, the icons on them descript as follows:

- : to next page.
- : to previous page.
- : to source menu.

Setting Items : to enter the setting item.



Page3 of SETTINGS MENU

In the SETTINGS MENU, there are 10 setting items in all. Touch one setting item to enter the setting item page. The icons on the setting item page descript as follows:

- : to next page.
- : to previous page.
- : to the page that the setting item belongs to.
- Setting Items : to set the sub-item.
- : to increase the value.
- : to decrease the value.

1) SYSTEM SETTING



Page1 of SYSTEM



Page2 of SYSTEM

(1) LED COLOR

It is for setting the color of the buttons illumination and the LCD backlight.

(2) BT


It is for switching BT mode ON or OFF.

(3) RESET SYSTEM

It is for restoring all user setting to zero.

- (4) BRIGHT
It is for setting brightness.
- (5) CONTRAST
It is for setting contrast.
- (6) COLOR
It is for setting color.
- (7) TINT
It is for setting tint.

2) SOUND SETTING



Page1 of SOUND



Page2 of SOUND


- (1) RADIO L/D
It is for switching between LOC and DX.
- (2) STEREO
It is for switching between MONO and STEREO.
- (3) SWF VOL
It is for setting SWF volume.
- (4) SWF FREQ
It is for setting SWF frequency.
- (5) LOUDNESS
It is for setting LOUDNESS mode.
- (6) SOUND EFFECT
It is for setting EQ mode.
- (7) TREBLE
It is for setting the value of treble .
- (8) BASS
It is for setting the value of bass.
- (9) FADE/BAL
After entering the sub-item, it displays as right:

Touching any place in the rectangle except the middle column sets the value of the balance; touching any place in the middle column sets the value of fade.

- (10) TOUCH BEEP
It is for switching touch beep ON or OFF.



Page3 of SOUND



FADE/BALANCE


3) BACKGROUND SETTING



BACKGROUND

It is for setting the background of the No Video interface for RADIO, CD, non-CD DISC/USB /CARD, AUX and BT MUSIC .

4) RDS SETTING



RDS

(1) REG SET

It is for setting REG on or off.

(2) PI SET

It is for switching between PI SOUND and PI MUTE.

(3) AF SET

It is for setting AF on or off.

(4) TA SET

It is for setting TA on or off.

5) GPS PATH SETTING



GPS PATH

It is for setting GPS path to enter GPS navigation mode. Please refer to the part of GPS navigation for detailed GPS path setting operation.


6) TIME SETTING



TIME

- (1) HOUR SET
It is for setting the hour of the clock time.
- (2) MINUTE SET
It is for setting the minute of the clock time.
- (3) TIME FORMAT
It is for setting the time format of the clock time.


7) TOUCH SETTING



TOUCH SCREEN CALIBRATION

It is for calibrating touch screen. Precisely and repeatedly tap the center of the cross cursor till it exit calibration interface.


8) INFO SETTING



SYSTEM INFO

It is for viewing the system information such as: name, version, memory size and free momery.

9) SKIN SETTING



SKIN

- (1) It is for setting the skin color of those immanent interfaces.
- (2) It is for setting the time of activating SCREEN SAVE after no operation.

10) ANGLE SETTING

It is for setting the angle of the control panel.

12. RESET button

When LCD displays wrongly or some buttons are not available or sound is distorted, press REL button to detach the control panel and remove it, then use the sharp end of a pointed object to press RESET button on chassis face to reset the program to zero.

13. REL button

To detach control panel, press REL button on control panel.

After detaching control panel, hold the right part of the control panel and pull it upwards a little and then you can remove it from chassis.

Radio Operation

1. To enter RADIO mode(MODE button or RADIO icon)

When you use MODE button or source menu (tapping RADIO icon) to enter RADIO mode, it will display radio interface as follows:



Radio interface



Radio interface with 1~6 icons interface

- * Some icons on radio interface correspond with the buttons on remote control or control panel as follows:

and icons = VOL- and VOL+ buttons = VOL knob
 icon = MUTE button
 : to display 1~6 icons interface in the left side of the radio interface.
 : to enter source menu
 : To pop up the page1 of SETTINGS MENU
 : To enter GPS mode but not exit radio mode

2. To switch between bands (BAND)

The BAND icon or button can switch between bands of FM1, FM2, FM3, AM1(MW1) and AM2(MW2), and the word FM1, FM2, FM3, AM1(MW1) or AM2(MW2) will be displayed on screen.

3. To search for a station (<< and >> icons or v and ^ or |<< and >>| buttons)

- 1) Long touching << or >> icon or long pressing v or ^ button on remote control or long pressing |<< or >>| button on control panel can automatically search down or up for an available station beginning from the current frequency.
- 2) Briefly touching << or >> icon or briefly pressing v/^ or |<</>>| button can manually search down or up for a your desired station beginning from the current frequency.

4. To preset and scan all memory stations (APS icon or A/PS button)

- 1) When long touching APS icon or long pressing A/PS button, the radio searches from the lowest frequency and checks the signal strength level until 1 cycle search is finished, and the 6 strongest stations are preset to corresponding preset number memory bank for the current band.

The presetting function can be implemented in selected FM or AM band. (It can presets 3x6 stations for FM and 2x6 stations for AM(MW) in all)

- 2) When briefly touching APS icon or briefly pressing A/PS button, the radio scans for each preset station in FM or AM(MW) band from NO.1 bank, each preset station broadcasts for 5 seconds. After finishing a circle of scanning, it will resume broadcasting the station in NO.1 bank.

NOTE: In FM band, FM1, FM2 and FM3 are preset and scanned as one band at a time; In AM(MW) band, AM1(MW1) and AM2(MW2) are preset and scanned as one band at a time.

5. To preset and listen to a memory station(1~6 icons or 1~6 buttons or CH1-6 button)

- 1) Long touching one of 6 number(1~6) icons or long pressing one of 6 number(1~6) buttons can preset the current broadcasting station of the current band in the number memory bank; .
- 2) Briefly touching one of 6 number(1~6) icons or briefly pressing one of 6 number(1~6) buttons can listen to the memory station in the current band preset in the number memory bank.

* CH1-6 button:

- 1)To preset a station in a memory bank with CH1-6 button, first select a desired band; then press CH1-6 button to select a desired memory bank; and then search for a desired station; finally long press CH1-6 button to store the station in the memory bank.
- 2)To listen to a preset station with CH1-6 button, first switch on a desired band, then continuously press CH1-6 button highlight and listen to it.

6. To switch on between stereo and mono mode (MO/ST button)

Press MO/ST button on remote control to select STEREO or MONO mode for FM band.

When the STEREO mode is activated, it can get better audio effect; when the MONO mode is activated, it can get clearer audio signal.

7. To switch on between local and distance mode (LO/DX button)

Press LO/DX button to turn LOC on to tune for local stations with weak interference;
Press LO/DX button to turn DX on to tune for distance stations with stronger signal.

8. To search for a RDS station that is broadcasting a typed program (PTY)

Continuously touching PTY icon on touch screen or continuously long pressing PTY button on control panel switches between the program types such as: NEWS ...and so on.

After selecting a desired program type, no operation for a while, it displays PTY SEEK and automatically searches for a RDS station that is broadcasting the selected type of program.

If the station that is broadcasting the selected type of program does not exist, it will display NO PTY and return back to the previous normal station.

9. To automatically alternate a stronger signal of frequency for the current RDS station(AF)

During broadcasting a program typed station, use the RDS interface of the SET-TINGS MENU or SEL and VOL buttons to set AF mode on or long press TA/AF button on control panel or AF button on remote control to switch on AF mode, then AF icon flashes on screen.

After switching on AF mode, the radio checks the signal strength of AF(alternate frequency) all the time. Whenever a new AF is stronger than the current frequency,

It switches over to the AF for a short time, and the AF icon is light on screen(not flash).

- * In FM mode, when switching on AF mode, the radio auto searches for or preset only those RDS stations.
- * In FM mode, when switching on AF and TA modes, the radio auto searches for only those RDS stations broadcasting traffic announcement.

10. REGION mode

use the RDS interface of the SETTINGS MENU or the SEL and VOL buttons to set REGION mode on or off.

In REGION on mode, when switching on AF mode, the radio can't switch over to those AF stations which have a different regional program content.

In REGION off mode, when switching on AF mode, the radio can switch over to those AF stations which have a different regional program content.

11. PI mode

use the RDS interface of the SETTINGS MENU or the SEL and VOL buttons to set PI SOUND or PI MUTE mode.

In PI SOUND mode, when switching on AF mode, if a car cruises that critical area back and forth, an oscillation phenomenon can be occurred, because the different PI code can be receive from a same AF. when the different PI sound (DIP) is heard once in a while, the different PI sound will be heard for less than 1 second.

In PI MUTE mode, when switching on AF mode and under above same situation, a mute sound will be heard for less than 1 second.

12. To automatically search for traffic announcements (TA)

In any mode, use the RDS interface of the SETTINGS MENU or SEL and VOL buttons to set TA mode on or press TA/AF button on control panel or long press TA button on remote control to switch on TA mode, then TA: ON will display on screen for a while and begin to search for those RDS radio stations transmitting traffic announcement.

When an RDS radio station transmits traffic announcement and is received by the radio, temporarily switch the current work source to an RDS radio station broadcasting traffic announcement, and TRAFFIC will be displayed on screen.

When the traffic announcement is over, it will return back to previous work source.

BT Operation

1. Pairing and Connecting

Prior to using the BT device named BC_HF_V03 as a handfree system for a BT-enabled mobile phone for the first time, you must pair and connect them as follows:

- * Prior to pairing and connecting, when displaying No Video interface of radio, CD, video disc, AUX or BT music, **BT** logo flashes in the top left corner of touch screen.
 - * During using the BT device named BC_HF_V03 as a handfree system for a BT-enabled mobile phone, place the BT-enabled mobile phone 3 meters from the Car A/V System;
- 1) Touch  icon on BT PHONE interface in the BT PHONE part or long press PAIR button on remote control or on control panel to display **BT**  logo;
 - 2). Switch on the BT mode of your mobile phone; then select the item to find a BT device and enter it; When it finds the BT device of the car A/V system, the name BC_HF_V03 will be displayed, select it and enter it; then it will show an interface that asks you to input a password, input 8888 and enter it; then it will pair and connect with the BT device BC_HF_V03 of the car A/V system, Confirm it, then **BT**  logo displays all the time.
- * When finishing pairing and connecting, the audio of the mobile phone transfers to the car audio system whenever a call is made or received or the mobile phone plays music.

2. BT PHONE

1) Make a call

- (1) Dial with mobile phone directly;
 - (2) Dial with the controls on BT PHONE interface or on remote control or on control panel
- a. Touch the BT PHONE icon on source menu or long press  button on remote control to pop up BT PHONE interface as follows:



: to strengthen the pairing signal.



: to exit BT PHONE interface.

b. Use the number icons or buttons to input your desired phone number;

* When inputting a wrong digit, use  icon or < button to delete it.

c. After finishing inputting, touch  icon or press  button on control panel or press  button on remote control to dial out.

2) Redial last dialed phone number

Touch  icon or long press  button on remote control to dial out the last dialed phone number.

3) Answer a call

During ringing, the incoming telephone number displays in the middle of the top column of the BT PHONE interface. If you want to receive it, touch  icon or press  button on control panel or press  button on remote control; if you want to reject it, touch  icon or press  button on control panel or press  button on remote control.

4) End phone talking

When you want to end phone talking, touch  icon or press  or  button.

5) Switch audio between car A/V system and mobile phone

During phone talking using the BT handfree system of the car A/V system, if you want to change the phone audio to your mobile phone, touch  icon or press  button on control panel or press  button on remote control.

During phone talking using the mobile phone, if you want to change the phone audio to the the car A/V system again, touch  icon or press  or  button.

6) Adjust volume level during phone talking


During phone talking, use  and  icon or VOL knob or VOL+ and VOL- buttons to adjust volume level.

* * / # icons and buttons

they perform as * / # buttons on mobile phone.

3. BT MUSIC

1) Touching BT MUSIC on source menu or pressing MODE button can pop up BT MUSIC interface as follows:



 and  icons = VOL- and VOL+ buttons = VOL knob

MUTE icon = MUTE button

 icon =  button

 icon =  button

 and  icons =  and  button

MUSIC icon: To enter source menu.

MENU icon : To pop up the page1 of SETTINGS MENU

MAP icon : To enter GPS mode but not exit BT music mode

- 2) When using your mobile phone with BT function to play audio/video, if it is paired and connected with the BT device of the car A/V system, the audio of the mobile phone will change into the car A/V system.

The BT device of the car A/V system support A2DP, if your mobile phone with BT function support A2DP, the car A/V system can output stereo audio from your mobile phone.

- 3) The BT device of the car A/V system supports AVRCP, so these icons on the BT MUSIC interface except MUSIC/MENU/MAP and their corresponding buttons on control panel or on remote control are available for audio/video playback of your mobile phone during playback. But no fast forward/backward functions for  icon and buttons, and the function of resume playback after pausing or stopping is available only for some mobile phone.

- * If you don't want to use the BT function of the car A/V system , long press SEL button to display BT, then use VOL knob or VOL+ and VOL- buttons to switch BT off .

Disc/USB/Card Operation


1. Loading or unloading a disc, USB or card

1.1 Loading a disc, USB or card


To play files in a disc, insert a disc with label surface up into disc slot. it will automatically play.

*** CAUTION OF USING DISC**



- 1) Handle a disc by its edge, do not touch the surface of play side
- 2) Before inserting disc, wipe the disc outwards from the disc center with a clean, soft, dry, lint-free cloth. Do not use solvents /thinner such as petrol/benzine, cleaner.
- 3) After taking a disc out of disc slot, put the disc inside disc case to keep it clean.
- 4) Do not stick paper or tape on the disc surface of play side. If there is glue (or analog) on the disc surface, must wipe it up before using.



To play files in a USB, firstly open USB port cover, then insert USB storage into USB port, and then it will play files in the USB automatically.



To play files in a card, firstly press REL button to detach control panel, then hold the right part of the control panel and pull upwards a little and to you to remove it, and then insert the card with label side upward and contact end frontward into card slot as the following fig., and then attach control panel onto chassis again, by now it will play files in the card automatically .



Press in till heard a "CLICK"

1.2 Unloading a disc, USB or card


To unload the disc in disc slot, use STOP button to stop playback and then press  button to eject disc, then remove it.

To pull away the USB storage, use STOP button to stop playback, then you can remove the USB storage.

To unload the card in card slot, use STOP button to stop playback, then press REL button to detach control panel and then hold the right part of the control panel and pull upwards a little and then to you to remove it, and then you can push the card for release it and then pull it out of card slot.



Press in till heard a "CLICK"



Remove the memory card


- * During MP3/WMA playback, the information of file, folder, title, artist and album will be scrolling on LCD display. As long as the current playing MP3/WMA music contains relevant ID3 tag information in version 1.0/2.0 format, the 3 items underlined above will be scrolling on LCD display; otherwise, they will not.
- * There is ESP function for all formats of discs.

2. Popping up Function Icons-board

2.1 Function Icons-board of Digital Video/VCD/MPEG4/Image/MP3/WMA

During Digital Video/VCD/MPEG4/Image playback, tapping any place on touch screen can pop up Function Icons-board 1 as next page, then tap  icon to pop up Function Icons-board 2 as next page.

During MP3/WMA playback, tapping any place except folder area, track area and MP3/WMA&Image&MPEG4 icons can pop up Function Icons-board 1 same as one of Digital Video/VCD/MPEG4/Image, then tap  icon to pop up Function Icons-board 2 same as one of Digital Video/VCD/MPEG4/Image.



The Function Icons-boards display as follows:




* Some icons on the Function Icons-boards describe as follows:

- | | |
|--|--------------------------------------|
| : Same as MUTE button. | : Same as EQ button. |
| : Same as VOL- button or rotating VOL knob with anti-clock wise. | : Same as CLK button. |
| : Same as VOL+ button or rotating VOL knob with clock wise. | : Same as long pressing EQ button. |
| : Popping up source Menu. | : Same as SW button. |
| : Popping up Function Icons-board 2. | : Switching AF mode on or off. |
| : Redialing the last phone number. | : Switching TA mode on or off. |
| : Popping up BT PHONE interface. | : Popping up Function Icons-board 1. |

2.2 CD interface

During CD playback, the CD interface displays as follows:



* For Digital Video/VCD/MPEG4/Image/MP3/WMA, after loading disc/USB/card, the screen will also display this interface above. After a while, it will disappear and display video or image or root menu.

* Some icons on the CD interface describe as follows:

and icons = VOL- and VOL+ buttons = VOL knob

MUTE icon = MUTE button

Disc icon: To enter source menu

MENU icon : To pop up the page1 of SETTINGS MENU

MAP icon : To enter GPS mode but not exit disc mode

3. Function of controls on the touch screen/main unit/remote control

1. icon or button

During playback, use it to pause playback; in pause mode, use it to resume playback.


In CD interface, the icon displays as .

2. icon or button

During Digital Video/VCD/CD/MP3/WMA playback, tapping or pressing it pre-stop or pause playback; in pre-stop or pause mode, use  icon or button to resume playback.

During playback, tapping or pressing it twice to fully stop playback; in fully stop mode, use  icon or button to start playback from the beginning of the media.

During MPEG4/image playback, use  icon or button to display root menu as follows:



During MP3/WMA playback, the root menu above displays all the time.

When displaying root menu, use < or > button to highlight the current chapter/track, the current folder or the kind icons.

- * If there are no track/chapter for a kind icon, you can't highlight the kind icon.

When highlighting a kind icon, press ENTER button to enter it.

When highlighting the current folder, use v or ^ button to highlight other folders and then press ENTER button to enter it.

When highlighting the current track, use v or ^ button to highlight other tracks and then press ENTER button to play it.

- * For image, after highlighting a track, press ENTER button to display only the highlighted track; press >|| button to display all tracks step by step from the highlighted track.

- * Tapping folder icon, track icon or kind icon can execute the operation above.

3. / icons or buttons

During playback, continuously tapping  or  icon or continuously pressing  or  button on remote control or continuously and long pressing  or  button

on control panel can fast backwards or forwards at the following multiple of normal speed: x2, x4, x8, x20, x1.

During fast playback, use  icon or button to resume normal playback.

For image files, no this function.

4.  /  icons or buttons
During playback, use one of them to play previous or next chapter/track.

5. Number buttons
During Digital Video/VCD(PBC OFF)/MPEG4/Image/CD/MP3/WMA playback, use number buttons to input chapter/track SN. , then it will play or display it.

To input a chapter/track with an SN that is equal to or bigger than 10, use the +10 button to input the digit in tens place and then use 0-9 button to input the digit in units order.

I.e. +10 ~ 1 = 11 (number 11 chapter/track will be displayed/played.)

During VCD playback, when it is in PBC ON mode, the number buttons are disabled.

6.  icon and MENU button
During Digital Video playback, use MENU icon or button to display the current chapter list, then use direction buttons to select your desired chapter and then press ENTER button to play it.

For VCD, MENU button is disabled, track list is displayed on the monitor screen by pressing TITLE/PBC button or tapping  icon.

For MPEG4/image, MENU button and  icon are disabled, root menu is displayed on the monitor screen by pressing  button or tapping  icon.

For MP3/WMA, MENU button and  icon are disabled, root menu displays on the monitor screen all the time. Root menu of MP3/WMA is same as the one of MPEG4/image.

For CD, the MENU button is disabled.

7.  icon and TITLE/PBC button
During Digital Video playback, use TITLE/PBC button or  icon to display title list; then use direction buttons to select your desired title and then press ENTER button to open the chapter list of the title; then use direction buttons to select your desired chapter and then press ENTER button to play.

- * You can also tap a desired title and then chapter to play.

During VCD playback, use  icon or TITLE/PBC button to switch PBC mode on or off. When PBC mode is switched on, it will play from the beginning of media till it displays a track list. When a track list is displayed, use the number buttons to select your desired track to play.

For MP3/WMA/MPEG4/image,  icon and TITLE/PBC button are disabled.

For CD, the TITLE/PBC button is disabled.

8. icon and GOTO button

For Digital Video/MPEG4/VCD/image/MP3/WMA, you can use , , , number and ENTER icons or GOTO, <, >, number and ENTER buttons to select a chapter /track or from a playback time point to play.

During playback, tap  icon or press GOTO button to display changeable playback information bar as follows:

	Title SN.	Chapter SN.	Elapsed time
Digital Video:	TT 01/10	CH 09/20	 0:01:38
MPEG4:	CHAP 01/01	  	0:01:38
VCD:	TRK 01/10	 PBC  	0:01:38
Image:	TRK 006/231	  	0:00:00  Disabled
MP3/WMA:	TRK 01/23	  	0:02:22

- * During playback, tapping  icon can also display the Goto Function icons-board as follows:



When displaying the changeable playback information bar, use  /  icon or < or > button to highlight title SN.(only for Digital Video) , chapter/track SN. or elapsed time of current chapter/track(disabled for image).

When highlighting title SN. or chapter/track SN. , use number icons or buttons to input desired SN. of title or chapter/track, then use ENTER icon or button to play the selected chapter/track.

When highlighting elapsed time of current chapter/track(disabled for image), use number icons or buttons to input desired playback time point for the playback time of the whole media for Digital Video/VCD and of the current chapter/track for MPEG4/MP3/WMA, then use ENTER icon or button to play from the playback time point.

For CD, GOTO button is disabled.

9. icon or ZOOM button

During Digital Video/VCD/MPEG4/image playback, use  icon or ZOOM button to switch zoom mode between ZOOM 2, ZOOM 3, ZOOM 4, ZOOM 1/2, ZOOM 1/3, ZOOM 1/4 and ZOOM OFF.

When zooming in video/image, use direction buttons to move video/image upwards, downwards, rightwards or leftwards.

When not zooming in image, direction buttons can switch on 4 fixed rotated angles between >=90 deg cw, <=90 deg ccw, ^=UP-DOWN and LEFT-RIGHT.

For MP3/WMA,  icon and ZOOM button are disabled.

For CD, the ZOOM button is disabled.

10. OSD icon or button

During Digital Video/VCD/MPEG4/Image/MP3/WMA playback, use OSD icon or button to display playback information bar as bellows:

Digital Video:	Title SN. Chapter SN. TT 01/10 CH 09/20  0:01:38 Elapsed time of current chapter				
	Audio track Subtitle Angle  1/2 MP1 1CH  OFF AN OFF				
	TT 01/10 CH 09/20  -0:00:16 Remaining time of current chapter				
	TT 01/10 CH 09/20  0:08:03 Elapsed time of current title				
MPEG4:	Chapter SN. CHAP01/01    0:00:51 Elapsed time of current chapter				
	CHAP01/01    -0:01:38 Remaining time of current chapter				
VCD:	Track SN. PBC mode Repeat mode TRK 01/10  PBC   0:01:30 Elapsed time of current track				
	TRK 01/10  PBC   -0:02:17 Remaining time of current track				
	TRK 01/10  PBC   0:03:31 Elapsed time of total media				
	TRK 01/10  PBC   -1:04:26 Remaining time of total media				
Image:	Track SN. TRK 006/231    0:00:00 Disabled				
	Track SN. TRK 006/231   				
MP3/WMA:	TRK 01/23    0:01:22 Elapsed time of current track				
	TRK 01/23    -0:01:52 Remaining time of current track				

For CD , OSD button is disabled.

11. icon or REPEAT button

During Digital Video playback, touch  icon or long press RPT button to switch repeat mode between REP CHAPTER, REP TITLE, REP ALL and REP OFF.

During VCD(PBC OFF)/CD playback, touch  icon or long press RPT button to switch repeat mode between REP 1, REP ALL or REP OFF.

During MP3/WMA/MPEG4/image playback, touch  icon or long press RPT button to switch repeat mode between REP1, REP FOLDER(or DIR), REP ALL or REP OFF.

During VCD(PBC ON) playback,  icon and RPT button are disabled.

12. icon or RDM button

During Digital Video/VCD(PBC OFF)/CD/MP3/WMA playback, tapping  icon or long pressing RDM button switches random mode on or off.

For MPEG4/image/VCD(PBC ON) playback,  icon and RDM button are disabled.

13. icon or INT button

During VCD/CD playback, tapping  icon or long pressing INT button switches intro mode on or off.

For Digital Video/MP3/WMA/MPEG4/image,  icon and INT button are disabled.

14. icon or button

During Digital Video playback, use  icon or button to switch between audio tracks (depending on the current playing media).

During VCD/CD playback, use  icon or button to switch audio channels between MONO L, MONO R, MIX MONO and STEREO.

For MPEG4/MP3/WMA/image,  icon and button are disabled.

15. icon or button

During Digital Video playback, use  icon or button to switch subtitle languages on or off(depending on the current playing media).

For VCD/MP3/WMA/MPEG4/image,  icon and button are disabled.

For CD, the  button is disabled.

16. icon or SETUP button

Use  icon or SETUP button to enter Media Setup Menu for setting up all media parameter values.

Use  icon or SETUP button to display Media Setup Menu(the default page is SYSTEM SETUP);

Media Setup Menu has 4 pages in all. When highlighting a page, tap the aim page icon or press > or < button to highlight another page;


After selecting a page, tapping the aim item icon or press ^ or v button to highlight a setup item in the selected page;

After selecting a setup item, tapping the aim value; or press > button to enter the setup item, then press v or ^ button to select a desired value, finally press ENTER button to confirm it.

After finishing setting, tapping EXIT icon or press SETUP button to exit Media Setup Menu to resume normal playback.

Description of the 4 pages:

1) **SYSTEM SETUP**



TV SYSTEM

This setup item is for setting up video system in NTSC, PAL or AUTO .

If you set a non-matched video system for playing a video, the playing video will display white-black or flash.

SCREEN SAVER

This setup item is for switching screen saver on or off.

TV TYPE

This setup item is for setting up video display size.

- (1) 4:3 PS: Choose this item when connecting a monitor with 4:3 screen. When playing video with 16:9 size, the left and right part of video will be cut out, and video will display in full screen.
- (2) 4:3 LB: Choose this item when connecting a monitor with 4:3 screen. When playing video with 16:9 size, the top and bottom part of the monitor screen will be turned into a black square .
- (3) 16:9: Choose this item when connecting a monitor with 16:9 wide screen.

PASSWORD

This setup item is for locking or unlocking parental control. The default mode is locked. The default unlocking password is 0000.

To lock or unlock parental control:

- (1) Highlight PASSWORD item and then press > or ENTER button to enter it;
- (2) Input password 0000;
- (3) Press ENTER button to confirm, then it will unlock or lock parental control.

- * Remove the section of the PASSWORD of the User Manual to keep this sensitive information confidential.

RATING


This setup item is for setting a new rating level of parental control.

- (1) First highlight PASSWORD item to see whether parental control is locked or not. If it is in locked mode, unlock parental control referring to PASSWORD above.
- (2) Highlight RATING item and press > or ENTER button to enter it, then use ^ or v button to select your desired rating level, and then press ENTER button to confirm.
- (3) Highlight PASSWORD item again and then press > or ENTER button to enter it, then input password 0000, and press ENTER button to lock parental control again.

DEFAULT

This setup item is to change all parameter back to the default factory values.

2) LANGUAGE SETUP



OSD LANGUAGE

This item is for selecting the type of language displayed on the screen except for subtitle language and menu language(dependent on current playing media).

AUDIO LANG

This item is for selecting the type of audio language(dependent on current playing media).

SUBTITLE LANG

This item is for selecting the type of subtitle language(dependent on current playing media).

MENU LANG

This item is for selecting the type of menu language(dependent on current playing media).

3) VIDEO SETUP**BRIGHTNESS**

For adjusting brightness of video output.

CONTRAST

For adjusting contrast of video output.

HUE

For adjusting hue of video output.

SATURATION

For adjusting saturation of video output.

SHARPNESS

For adjusting sharpness of video output.

4) DIGITAL SETUP



DYNAMIC RANGE

This item is for adjusting linear compression ratio. If you set it to FULL, Peak-to-Peak value of audio signal is minimum; if you set it to OFF, Peak-to-Peak value is maximum.

*** Region Code**

If you insert a disc into the disc slot and REGION ERROR is displayed, the car multi-media system can not play the disc. The reason is that the region codes of the car multi-media system and the used disc do not match each other.

Appendix: Region code of Digital Video

Motion Picture Association of America (MPAA) divided the world into 6 regions, and gave every region a region code for locking and unlocking Digital Video playback.

Basically, a coded Digital Video player can play only the discs if its region code is the same as the code of the Digital Video player. Otherwise, it cannot play the disc.

Please note that only the Digital Video discs and Digital Video players produced by the 8 biggest film-making companies of America impose this restriction. The Digital Video discs and Digital Video players not produced by the 8 biggest film-making companies of America are not restricted by the rule of region code. Generally, they are called Free Region Code or Full Region Code.

The problems caused by area code inconsistency has motivated the production of unlocked version Digital Video players and recodable Digital Video players .

Region codes and the countries or areas represented by region codes are as follows:

Region 1: America, Canada, East-Pacific Inlands;
Region 2: Japan, West Europe, North Europe, Egypt, South Africa, Middle East;
Region 3: South-east Asian countries include Taiwan, Hong Kong, South Korea, Thailand, indonesia, etc.;
Region 4: Australia, New Zealand, Central South America, South Pacific Inlands;
Region 5: Russia, Mongolia, Indian Peninsula, Middle Asia, East Europe, North Korea, North Africa, North-west Asia etc.;
Region 6: China mainland.

The 8 biggest film-making companies of America are as follows:

1. WarnerBros;
2. Columbia;
3. 20thCenturyFOX;
4. Paramount;
5. Universal;
6. UA(UnitedArtist);
7. MGM(MetroDogwynMayer);
8. WaltDisney

*** Parental Control**

Q: After inserting a Digital Video disc into the disc slot, if a dialogue box pops up and asks you to input a password, what should you do ?

A: The playing disc is locked by a rating level of parental control. If the current rating level of parental control of the Digital Video player is lower than the one of current disc, you must input the correct password of parental control to unlock the parental control and enter a rating level equal to or higher than one of the current disc in order to play the disc.

* For factory preset password of parental control of Digital Video player, please see the part of Media Setup Menu.

Appendix: Parental Control

Parental Control function of a Digital Video player can control playback of movie ratings on a disc. You can set the Digital Video player to be a certain rating level of parental control using the Media Setup Menu. If the rating level of parental control of a disc is higher than the one of the Digital Video player, the Digital Video player cannot play the disc.

The Digital Video movie can be designed so that the Digital Video player can play different versions of content of a particular movie according to the different rating levels of parental control. Depending on the Digital Video features, the scenes that are not suitable for children will be cleared or replaced by suitable scenes automatically.


The rating levels of Parental Control are as follows:

- | | |
|---|----------|
| 1 | Kid Safe |
| 2 | G |
| 3 | PG |
| 4 | PG 13 |
| 5 | PG R |
| 6 | R |
| 7 | NC 17 |
| 8 | Adult |

AUX IN operation

An external AV system can use the car AV system as monitor and amplifier.

1. Use an AV cable to make the car AV system and the external AV system connected through the AUX IN jack on control panel of the car AV system and the AV Out jacks of the external AV system.



2. Play the external AV system, then use MODE button or Source Menu to enter AUX IN mode for the car AV system. By now, the program played by the external AV system can be output through the monitor of the car AV system and the speakers connected to the car AV system.



- * The icons on the AUX interface describe as follows:


and icons = VOL- and VOL+ buttons = VOL knob
MUTE icon = MUTE button
EQ icon = EQ button
LOUD icon = long pressing LOUD button
SWF icon = long pressing SW button
AUX icon: To enter source menu
MENU icon : To pop up the page1 of SETTINGS MENU
MAP icon : To enter GPS mode but not exit AUX mode

3. In AUX IN mode, you can use SEL, +, -, VOL, MUTE, EQ, SW and LOUD buttons or icons to adjust audio and video.


External iPod operation

An external iPod can use the car AV system as a monitor and amplifier.

1. Use the iPod cable to make the car AV system and the external iPod connected through the AUX IN jack on control panel of the car AV system and the headphone port of the external iPod.



2. Play the external iPod, then use MODE button to enter AUX IN mode for the car AV system. By now, the program played by the external iPod can be output through the monitor of the car AV system and the speakers connected to the car AV system.



- * The icons on the AUX interface describe as follows:

and icons = VOL- and VOL+ buttons = VOL knob
MUTE icon = MUTE button
EQ icon = EQ button
LOUD icon = long pressing LOUD button
SWF icon = long pressing SW button
AUX icon: To enter source menu
MENU icon : To pop up the page1 of SETTINGS MENU
MAP icon : To enter GPS mode but not exit iPod mode

3. In AUX IN mode, you can use SEL, +, -, VOL, MUTE, EQ, SW and LOUD buttons or icons to adjust audio and video.

REAR VIEW CAMERA

The car AV system can make you look at the actual status behind your car when you change the gear level to the back position.

1. Use an video cable to make the car AV system and the rear view camera connected through the REAR CAMERA INPUT jack in the rear cabinet of the car AV system and the VIDEO OUTPUT jack of the rear view camera.

Make the REAR CAMERA SWITCH line in the rear cabinet of the car AV system connected to (B+)12V power supply.

2. When you change the gear level to the back position, the screen of the car AV system will display the actual status behind your car.

* Note : the external monitor can not display the actual status behind your car.


Operation of GPS module

1. GPS Navigation

1. Loading GPS card

Before setting GPS path and entering GPS navigation mode, must load a GPS card with navigation map program file into the GPS card slot.

firstly press REL button to detach control panel, then hold the right part of the control panel and pull upwards a little and to you to remove it, and then insert the GPS card with label side upward and contact end frontward into the GPS card slot as the following fig., and then attach control panel onto chassis again.



2. Setting GPS path

After loading GPS card and before entering GPS navigation mode, must set the GPS path to an executable navigation map program file.

Touch SYSTEM icon on the setup page of the source menu to pop up page1 of SETTINGS MENU, then touch the item of GPS PATH SETTING to pop up GPS PATH interface as follows:



GPS PATH

: to enter the card in the GPS card slot and select a desired executable navigation map program file(generally the extension name of an executable navigation map program file is exe) .

AUTORUN : If touching the white rectangle for ticking it, it will enter GPS mode automatically after resetting the unit or switching the ignition off and then power on the unit again.

NAVI VDI : If touching the white rectangle for ticking it, when GPS and another work source of radio, disc, USB, card, AUX or BT are working at the same time, the audio of radio, disc, USB, card, AUX or BT music and the navigation voice are available. When outputting navigation voice, the audio of radio, disc, USB, card, AUX or BT music is mute; when no outputting navigation voice, the audio of radio, disc, USB, card, AUX or BT music is available. If no ticking it, the navigation voice is mute when GPS and another work source are working at the same time.

Back : to exit to the page1 of SETTINGS MENU.

3. Entering GPS navigation mode.

After loading a GPS card with an executable navigation map program file and set the GPS path to the executable navigation map program file, touch the GPS icon in the home page of the source menu or touch the MAP icon in the top right corner of the No Video interface of radio, CD, video disc, AUX or BT music to enter GPS navigation mode.


- * If using the GPS icon in the home page to enter GPS mode, it will exit the working source; if using the MAP icon in the top right corner of the No Video interface of radio, CD, video disc, AUX or BT music to enter GPS mode, it will not exit the working source. In GPS mode, use MODE button to enter radio, disc, USB, card, AUX or BT music mode, it will not exit the working GPS mode.

About navigation operation for details, please refer to the User Manual of the navigation map.


2. MEDIA/PHOTO/VIEWER

Media Operation

After loading a GPS card with MP3/WMA/MPEG4 files, touch MEDIA icon in the tools page of the source menu to enter media mode and pop up the media interface as follows:



Media interface



Track/chapter list of current MP3/WMA/MPEG4

- : to pause or resume playback.
- and : to play next or previous track/chapter after selecting more than 2 tracks.
- : to mute or resume sound.
- : to enter full-screen mode for MPEG4 or to pause or resume playback for audio.
- and : to increase or decrease volume level.
- : to enter the track/chapter list of current MP3/WMA/MPEG4.
- : to exit to source menu.

Screen except key board: pause or resume playback.

progress tape: touch it in progress tape to skip forward or backward to this point.

- : to open the folder list of the GPS card.
- File : touch a or some files to select it or them.
- : to select all tracks/chapter in the current MP3/WMA/MPEG4 folder.
- : to play the selected track(s)/chapter(s).
- : to exit the track/chapter list to media interface.
- Name : to reorder the tracks/chapters in the current folder by file name.
- Type : to reorder the tracks/chapters in the current folder by file type.
- Size : to reorder the tracks/chapters in the current folder by file size.
- Date : to reorder the tracks/chapters in the current folder by file date.
- Slide bar: slide it to slide the track/chapter list down or up.

Photo Operation

After loading a GPS card with photo files, touch PHOTO icon in the photo page of the source menu to enter photo mode and pop up the photo interface as follows:





Photo interface



GPS card path interface




Photo list

: to enter the GPS card path interface.

: to enter.

: to exit to photo interface.

SDMEM : to enter the data folders list step by step and finally enter photo list.

[.]: To return back to previous interface.

Slide bar: to slide the photo list downward/upward or rightward/leftward.

File : to enter photo interface again and display the photo of this file.

: to zoom out the current photo.

: to display the current photo with the scale of 1:1.

: to zoom in the current photo.

: to display previous photo with the scale of 1:1.


: to display next photo with the scale of 1:1.

: to enter full-screen mode.


: to exit the photo interface to the tools page of the source menu.

Reader Operation

After loading a GPS card with e-book files its extension name are txt, touch READER icon in the tools page of the source menu to enter Reader mode and pop up the reader interface as follows:




Reader interface



E-book list

-  : to enter the GPS card path interface.
- SDMEM : to enter the data folders list step by step and finally enter e-book list.
- File : to enter Reader interface again and display the e-book of this file.
-  : to the home page.
-  : to automatically slide page upward or stop sliding.
-  : to the end page.
-  : to previous page.
-  : to next page.
-  : to pop up the information interface of the current e-book.
-  : to pop up the e-book setting interface.
- Reader : to exit Reader interface to the tools page of the source menu.




information interface of the current e-book




E-book setting interface

-  : to exit the information interface of the current e-book to Reader interface.
-  : touch it to open the scroll speed list and then touch one of them to set it.
-  : touch it to open the font size list and then touch one of them to set it.
-  : to pop up the word color setting interface.
-  : to pop up the background color setting interface.
-  : to confirm the setting and exit to Reader interface.
-  : to exit to Reader interface.



Word color setting interface




Background color setting interface

- R slide bar : to set tint of red color.
- G slide bar : to set tint of green color.
- B slide bar : to set tint of blue color.
-  : to confirm setting and exit to the e-book setting interface.
-  : to exit to the e-book setting interface.

Calculator and Calendar

1. Calculator

Touch CAL icon in the tools page of the source menu to pop up calculator interface as follows:




Calculator interface

- MC** : to clear the number in the memory.
- MR** : to display the number in the memory as inputting a number during arithmetic operation.
- MS** : to store the current displaying number in the memory and display M in the left side of the display frame.
- M+** : to make the current displaying number and the number in the memory plused and store it in the memory.
- +/-** : to change the current displaying number into positive or negative one.
- CE** : to clear the current displaying number.
- C** : to reset the calculator to zero.
- ←** : to clear the last input digit.
- CAL** : to exit to the tools page of the source menu.

* The memory can store only the last number.

2. Calendar

Touch DAY icon in the tools page of the source menu to pop up calendar interface as follows:



Calendar interface

- 13** : to select the desired date.
- October** : to select the desired month.
- 2011** : to select the desired year.
- DAY** : to exit to the tools page of the source menu.

GAME

1. MINE

Touch MINE icon in the games page of the source menu to pop up MINE game interface as follows:



MINE game interface




LINK game interface

2. LINK


Touch LINK icon in the games page of the source menu to pop up LINK game interface as above.

3. FIVE CHESS

Touch FIVE CHESS icon in the games page of the source menu to pop up FIVE CHESS game interface as follows:



FIVE CHESS game interface



BW CHESS game interface

4. BW CHESS

Touch BW CHESS icon in the games page of the source menu to pop up BW CHESS game interface as above.

5. MOLE

Touch MOLE icon in the games page of the source menu to pop up MOLE game interface as follows:



MOLE game interface

Troubleshooting

Please read the user manual carefully before using the car A/V system. If you have any difficulty using this car A/V system, refer to the troubleshooting guide. If you are still unable to resolve the problem after using all the suggestions, please contact your dealer or an authorised service centre .

NO PICTURE, SOUND

- * Ensure that the power switch is on.
- * Ensure that the power cord is not damaged or the fuse is not blown.

NO SOUND BUT HAVE PICTURE

- * Ensure that the player's audio output is properly connected to the speaker's audio input.
- * Check whether the audio connector is damaged.
- * Check whether you have turned down the volume.
- * Ensure that the audio is not in MUTE mode.

BLACK AND WHITE PICTURE OR SCREEN ROLLING

- * Ensure that you have set right mode of video system (e.g. PAL, NTSC).

FLAWS OF PICTURE OR SOUND

- * Check whether disc is scratched or stained.
- * Check whether AV connector and output terminal is stained.
- * Check whether there is condensation inside the lens. If so, power on the player and do not work for an hour or so, then try again.

DISPLAYS: NO DISC OR BAD DISC

- * Ensure that you have inserted a disc into the disc slot.
- * Check whether disc is inserted with label side upwards.
- * Check whether disc is bent.
- * Check whether disc is stained or scratched badly.
- * Ensure that disc format is compatible to the player.
- * Ensure that temperature inside the car is not too high. If so, cool off until the ambient temperature returns to normal.
- * Insert another disc into the disc slot.

REMOTE CONTROL IS INSENSITIVE OR DOES NOT WORK

- * Check whether the lithium cell of the remote control is powerful and working properly.
- * Direct the IR emitting window of the remote control to the IR sensor of main unit.
- * Check whether there are some obstacles between remote control and main unit.

SOME FUNCTION BUTTONS DO NOT WORK

- * Turn off ACC power, then turn on again.
- * Reset unit to zero, then turn on again.
- * Remove control panel from chassis, reattach it onto the chassis and then turn it on again.

RADIO DOES NOT WORK

- * Check whether antenna cable is connected firmly.
- * Manually tune for a station.

Specification

General

Power Supply Requirement.....DC 12V
Current consumption.....10A MAX.

Audio

Signal Output.....2ch&4ch line out
Frequency Response.....20 Hz - 20 KHz
S/N Ratio.....90 dB (JIS)
Wow and Flutter.....Below measurable limits

TFT Monitor

Monitor Screen Size.....7 Inch Wide
Color System.....NTSC/PAL

Disc/USB/Card

Compatible Format....Digital Video/MPEG4/VCD/IMAGE/MP3/WMA/CD

Radio

FM

Frequency range.....87.5MHz - 107.9MHz
Usable sensitivity.....15dBu
I.F Frequency.....10.7MHz

AM(MW)

Frequency.....530KHz - 1710KHz
Usable sensitivity.....40dBu
I.F Frequency.....450KHz

BT:

BT specification.....V1.2 Class 2
BT profile supporte.....
.....Headset, Handsfree and A2DP & AVRCP profiles
Range of frequency.....2.4GHz Spectrum

NOTE:

Specification and design are subject to modification, without notice,
due to improvements in technology.

MADE IN CHINA

88-J8308-06C



Visit us @ pyleaudio.com

IMPORTANT: Pack carefully in original package if possible. We are not responsible for damage incurred in returning items for repair. A letter stating your exact street address, daytime phone number, and the problem you are experiencing should be included. You must also enclose a copy of the original receipt a sproof of date of purchase

Brooklyn, NY 11204

1-800-444-5671

Monday Through Thursday, 9AM to 5PM

Friday 9AM to 1PM Eastern.